



Caution: Unplug AC adaptor when wiring

## Wiring for new ZM Zone Manager to RC-001T Module

Link A shown only

## Connecting the new ZM-9000 modules, ZM-9011, 9012, 9013, 9014

- The TOA RC-001T remote control module provides two connection paths for the new ZM-9000 Zone Management controllers. *Each path or link can host up to 8 controllers depending on cable length.*
- Connection of these controllers to the RC-001T is by **shielded** CAT5 or one twisted pair **shielded** (data) and one twisted pair (power)
- Do not connect Link A to Link B at any time. Remove the AD-246 power adaptor when wiring the ZM controllers as this power appears on the power lines even when the 9000M2 is turned off.
- After programming the ZM modules using the TOA software, you must do an **ALL DATA** upload as the parameters associated with the ZM modules are not scene based and uploading a single scene will not send the controller parameters. Failure to do so may show a 9000M2 front panel FAULT indication.
- Follow the diagram illustrated for wiring and check the manual for cable length versus maximum controllers allowed. **Link A** shown only, **Link B** wired the same.

*For additional help please call 1-800-263-7639 or 905-564-3570 and ask for Tech support.*