

Wireless Microphone Selection Guide

»» TOA 5000 Series Wireless Microphone Selection Guide

Description	Model	Replaces	Compatible With
Handheld Wireless Microphones			
Handheld microphone, condenser, unidirectional	WM-5225	WM-5220	Receiver: WT-5800; WT-5805; WT-5810; WT-4820
Handheld microphone, dynamic, unidirectional	WM-5265	--	
Handheld microphone, dynamic, unidirectional	WM-5270	--	
Beltpack Transmitter (microphone sold separately)			
Wireless beltpack transmitter	WM-5325	WM-5320; WM-5320A; WM-5320H	Microphones: Q-EM-22; Q-HM-22; WH-4000A; WH-4000H; YP-M5300; YP-M5310; Battery: WB-2000-2 Battery Charger: BC-5000-2; BC-5000-6; BC-5000-12
Wireless Microphones			
Lavaliere microphone, condenser, unidirectional	YP-M5300	WM-5320;	Transmitter: WM-5325 Receiver: WT-5800; WT-5805; WT-5810; WT-4820
Lavaliere microphone, condenser, omnidirectional	YP-M5310	100012769A	
Headset microphone, condenser, unidirectional	WH-4000H	WM-5320H	
Aerobic headset microphone, condenser, unidirectional	WH-4000A	WM-5320A	
Headworn microphone, condenser, omnidirectional	Q-HM-22	--	
Single ear microphone, condenser, omnidirectional	Q-EM-77	--	
Optional Accessories - Microphones			
Battery charger for 2 microphones (AC adapter sold separately)	BC-5000-2	--	Microphone/Beltpack: WM-5225; WM-5265; WM-5325 AC Adapter: AD-5000-2
Battery charger for 6 microphones (AC adapter sold separately)	BC-5000-6	--	Microphone/Beltpack: WM-5225; WM-5265; WM-5325 AC Adapter: AD-5000-6
Battery charger for 12 microphones (AC adapter sold separately)	BC-5000-12	--	Microphone/Beltpack: WM-5225; WM-5265; WM-5325 AC Adapter: AD-5000-6
AC adapter (sold separately)	AD-5000-2	--	Battery charger: BC-5000-2
AC adapter (sold separately)	AD-5000-6	--	Battery charger: BC-5000-6; BC-5000-12
Battery	WB-2000-2	--	Microphone/Beltpack: WM-5225; WM-5265; WM-5325
Aerobics waist pack (belt)	WH-4000P	--	Microphone: WH-4000A
Replacement windscreen	WH-4000S	--	Microphone: WH-4000A; WH-4000H
Wireless Receivers			
True diversity receiver	WT-5800	--	Microphone: WM-5225; WM-5265; WM-5270; WM-5325
Space diversity receiver	WT-5805		
Space diversity receiver	WT-5810		
Wireless microphone receiver	WT-4820		
UHF wireless tuner module	WTU-4800	--	Module for WT-4820
Optional Accessories - Receivers			
Antenna distributor	WD-4800	--	Receiver: WT-5800; WT-5805; WT-4820
UHF wireless antenna	YW-4500	--	Receiver: WT-5800; WT-5805; WT-4820; WTU-4800
Rack mount for single receiver (1RU)	MB-WT3	--	Receiver: WT-5800; WT-5805; WT-4820
Rack mount for dual receiver (1RU)	MB-WT4	--	Receiver: WT-5800; WT-5805; WT-4820
Rack mount kit	MB-15B	--	Antenna distributor: WD-4800
Wireless Microphone Kits (includes Microphone and Receiver)			
Handheld condenser kit	WS-5225	WS-5200	Microphone: Q-EM-77; Q-HM-77; WH-4000A; WH-4000H; YP-M5300; YP-M5310
Handheld dynamic kit	WS-5265	--	
Lavaliere condenser (unidirectional) kit	WS-5325U	WS-5300	
Lavaliere condenser (omnidirectional) kit	WS-5325M	--	
Headworn condenser (unidirectional) kit	WS-5325H	WS-5300H	

»» TRANTEC Series Wireless Microphone Selection Guide

Optional Microphones			
Lavaliere microphone	MIC-X2; MIC-X55; MIC-X212-BE; MIC-X212-BK	Beltpack: S5.5-BTX; S5.3-BTX	
Lavaliere microphone	MIC-LP2; MIC-SJ55; MIC-SJ212-BE; MIC-SJ212-BK	Beltpack: S4.16-BTX; S4.4-BTX	
Glasses frame microphone	MIC-X690H	Beltpack: S5.5-BTX; S5.3-BTX	
Glasses frame microphone	MIC-SJ690H	Beltpack: S4.16-BTX; S4.4-BTX	
Headworn microphone	MIC-X33; MIC-X66-BK; MIC-X66-BL; MIC-X66-YE; MIC-MIC-X22-B-R; MIC-X22-P-R; MIC-XEM77;	Beltpack: S5.5-BTX; S5.3-BTX	
Headworn microphone	EM-77	Beltpack: S5.5-BTX	
Headworn microphone	MIC-SJ33; MIC-SJ66-BK; MIC-SJ66-BL; MIC-SJ66-YE; MIC-MIC-SJ22-B-R; MIC-SJ22-P-R; MIC-SJEM77	Beltpack: S4.16-BTX; S4.4-BTX	
Optional Accessories - Receivers			
Antenna distributor	S5-ADU	Receiver: S5.5-RX; S5.3-RX; S4.16-RX; S4.4-RX	
Antenna booster	YW-7000 RF		
Passive antenna splitter	ACC-SPLIT-2W		
Directional antenna	YW-7570		
Omnidirectional antenna	YS-7520		
Wall mount antenna	YW-4500 (when used with WD-4800)		
Whip antenna	ANT-54 BTX-D/BTX-G		
Antenna extension cable	LD-BNC-TNC		
TNC rack mount panel	PAN-1U19-TNC		
Blank panel	MW-1U-BLANK		
Receiver antenna	ANT-S5 RX-D/RX-G	Receiver: S5.5-RX; S5.3-RX	
Rack mount kit	ACC-S5RX-MBI; ACC-S5RX-MB3; ACC-S5RX-MB2	Receiver: S5.5-RX	
Antenna distributor	WD-4800	Receiver: S4.16-RX; S4.4-RX	
Power Supply (required)	100072907A	Receiver: S4.16-RX; S4.4-RX	
Helical antenna	ANT-54 HDX-D/HDX-G		
Antenna extension cable	LD-TNC ADU		
Guitar cable	LD-SJ-JAC		
Neoprene aerobic belt	ACC-AB1000		
Rack tray	ACC-S4.16RK		
Receiver antenna (required)	D021203010; D021202280	Receiver: S4.16-RX	
Rack tray	ACC-S4.16HWRK		
TNC M to BNC F Connector	15-6628	S4.16 Series	

Note: Please inquire with customer service or your Regional Sales Manager as some of the TRANTEC accessories / microphones may not be available. The AC Adapter for the 5000 Series battery chargers are sold separately. The antenna and power supply are not included with the S4.16-RX Receiver.